

TECHNICAL BULLETIN TB-63

Issue No. 01

Date 29/05/08

Author JH

Do not remove pulley protection cap!



When mounting the unit onto the vehicle make sure the cap remains on the pulley for protection. Its function is to prevent water/dust/debris ingress causing corrosion which seriously affects the lifetime of the clutch pulley.

Without the plastic cover a warranty claim is considered invalide!